

## How do I update the software version on my Ti5, Ti7 and Ti10 displays?

This guide outlines the steps for downloading and updating the software versions of Hexagon Agriculture's Ti5, Ti7 and Ti10 displays.

**Tip:** Keeping your software updated offers multiple benefits! It enhances security, support, improves stability by addressing bugs, and optimizes performance. Besides that, each new version introduces new features based on user feedback and advancements.

### 1. How can I download the latest software version?

To download the latest software version, access our [Release notes](#) which contains the latest software versions for each display. Click on your display type to initiate the download of the file to your computer.

**Note:** In our **Release notes**, besides finding the latest software versions, you can check all new developments, new improvements, bug fixes and future developments!

### 2. How do I update the display version (.uti)?


First of all, you will need to insert the downloaded file in a flash drive. Then, once you have inserted the flash drive in your display, follow the steps below:

**Note:** [Click here](#) if you'd rather watch a video tutorial on how to perform this process.


1. Select the **Settings** menu on the operation screen.



2. Then, select the **Settings** option




3. Next, click on **System mode** to switch it from **Normal** to **Advanced**.



**Tip:** Activating the **Advanced** mode will grant you access to specific features. When attempting to switch system modes, you will need to enter a password. If no password has been set up yet, you can bypass authentication by leaving the password field empty and selecting **OK**.


4. Once you've switched to **Advanced** mode, click on **About**.




5. Select the **System manager** option.



6. Then, you will see a pop-up message warning you that the equipment will have to be restarted later. Press **Yes**.




7. In the System manager screen, select **Update**.




**Warning:** For the update to be available, the flash drive containing the .uti file with the desired version must have been inserted into the display.


8. Now, select the **Install software update** option.




9. Select the update you want to install and press **Yes** to confirm the installation.



10. A progress bar will be displayed. Once it is completed, press **Ok**.



11. The display will return to the System manager screen and you should press Power off and the display will turn off.



12. You have completed the software update! Upon powering on your display, it will feature the newly installed version!